












- UA** Інструкція монтажу
RU Инструкция монтажа
KZ Құрастыру нұсқаулығы
D Montageanleitung
NL Handleiding voor de montage
TR Montaj talimatı
FR Instructions de montage
CZ Montážní návod
HU Összeszerelési útmutató
GB Assembly instructions
PL Instrukcja montażu
IT Istruzioni di montaggio
RO Instrucțiuni de asamblare
SK Montážny návod




LUS/12/7




A	B	C (mm)		D
1	M129-402-01	1170	740	1/1






I












II



III



IV

**1****2**

3

